


CONNECTOR



TO HOST MCU : UART
 GPIO_2/RESET : INTERRUPT FROM MCU TO DA
 FF OUT : INTERRUPT FROM DA TO MCU

DA16200 WIFI MODULE

